ESPEnhanced Steering Performance





ESP

Enhanced Steering Performance

Produced and published by Permobil AB, Sweden Edition 2, 2008-1

Product code: 205008-US-0

How to contact Permobil

Permobil Inc.

300 Duke Drive Lebanon, TN 37090

PH: 800.736.0925 FAX. 800.231.3256 info@permobil.com

Head Office of the Permobil group

Permobil AB

Box 120 861 23 Timrå Sweden

Tel: +46 60 59 59 00 Fax: +46 60 57 52 50 E-mail:info@permobil.com ESP User Manual Contents

Contents

Introduction	6
Safety rules	7
Programming	8
Parameter settings	9
Program version	10
Troubleshooting	10
Resetting the factory settings and calibrating the sensor	11

ESP User Manual Introduction

Introduction

The task of the ESP module is to give your wheelchair safer driving properties. ESP stands for Enhanced Steering Performance.

The ESP module is programmed by Permobil to give the wheelchair optimum performance. Customization may mean that small adjustments are necessary afterwards. Adjustments to the preprogrammed parameters may only be made by an engineer with good knowledge of the ESP module.

The ESP module is installed on the wheelchair chassis. See the chassis service manual for further information.

The ESP module is connected between the wheelchair actuator and the output stage, Pilot+. The module contains a sensor that measures the wheelchair's course deviations. A processor uses the information to correct any deviations from the course the user set using the wheelchair actuator. The ESP module uses the information from the sensor and the actuator to calculate a correct control signal. The control signal is then passed to the wheelchair output stage, Pilot+, which controls the drive motors.

Operation of the ESP module requires access to the full capacity of the output stage. Pilot+'s various parameters therefore need to be adjusted to predefined values to guarantee full maneuverability.

NB. The parameters in the Pilot+ output stage are set by Permobil and must not be changed. If changes need to be made to the wheelchair properties, they must be made via adjustments to the ESP module. The ESP module has built-in functions to control wheelchair performance, acceleration, course stability, etc.

ESP User Manual Safety rules

Safety rules

No changes may be made to the Pilot+ output stage parameters.
Reprogramming with PP1c, ESP PC Programmer or similar equipment may not take place.

- The ESP module may only be programmed by engineers who have good knowledge of ESP functions.
- Changes made to the parameters of the ESP module must be documented. Note the values of the parameters before and after changes.
- The ESP module is supplied preprogrammed for best performance. Any change to a parameter's value should mean a reduction in the value. Increasing a parameter's value may cause the wheelchair to become unstable and hard to maneuver.
- When changes have been made to the ESP module parameters, the wheelchair must be test-driven before it is returned to the user.

NB. If tests are carried out with the ESP module disconnected, you should be aware that the control characteristics are set to very high values. This makes the wheelchair hard to maneuver. Ensure that there is adequate free space around the wheelchair where the test is carried out.

ESP User Manual Programming

Programming

The ESP module has 16 adjustable parameters. Changes are made to the values of the parameters using three buttons on the front of the module. The ESP module is installed on the wheelchair chassis For further information on its location, see the chassis service manual.

1. Hold down the "S" button while starting the wheelchair with the main power switch on the control panel. The ESP module display displays "P1".

NB If the wheelchair has an additional joystick, the ESP module display displays "CJ" for a short while. This means that the joystick's neutral position is being calibrated. Ensure that the joystick is in its neutral position on startup. If it is not, the calibration will fail and the error code "E6" will be displayed. Error codes are discussed on page 10.

- Release the "S" button. The display displays "01", which means parameter no. 1.
- 3. Using the plus or minus button, you can step through the various parameters.
- **4.** Press the "S" button to read the value for the parameter selected.
- **5.** Using the plus or minus button, you can increase or reduce the value of the parameter selected.
- **6.** Press the "S" button to save the value set. The display returns to displaying the parameter number.
- 7. Scroll with the plus or minus button to another parameter.
- **8.** Exit the programming mode by switching off the wheelchair with the main power switch on the control panel.



ESP module front panel.

Example:

The wheelchair is too fast in speed position 5.

To reduce the maximum speed, go to the programming mode and step to parameter 9.

Press the "S" button to see the current setting. Adjust the value downwards using the minus button.

Save the value set by again pressing the "S" button.

Switch off and then start the wheelchair with the main power switch on the control panel to test-drive the wheelchair.

Remember that the maximum speed is reduced if the seat lift is raised. The seat lift must, therefore, be in its lowest position during the test drive.

Parameter settings

Number	Standard	Range*	Min.	Мах.	Step	Designation
1	15	10 - 75	5	95	5	Max. acceleration (speed 5)
2	15	5 - 50	5	95	5	Max. acceleration (speed 1)
3	75	20 - 75	5	95	5	Max. deceleration (speed 5)
4	30	10 - 70	5	95	5	Max. deceleration (speed 1)
5	40	25 - 75	5	95	5	Max. turn acceleration (speed 5)
6	15	10 - 50	5	95	5	Min. turn acceleration (speed 1)
7	60	35 - 80	5	95	5	Max. turn deceleration (speed 5)
8	40	30 - 60	5	95	5	Min. turn deceleration (speed 1)
9	95	20 - 95	5	95	5	Max. forward speed (speed 5)
10	15	10 - 80	5	95	5	Min. forward speed (speed 1)
11	25	10 - 50	5	95	5	Max. reverse speed (speed 5)
12	10	10 - 30	5	95	5	Min. reverse speed (speed 1)
13	80	50 - 90	5	95	5	Max. turning speed (speed 5)
14	65	25 - 80	5	95	5	Min. turning speed (speed 1)
15	2	N/A	1	5	1	Attendant high speed selection
16	1	N/A	1	5	1	Attendant low speed selection

^{*} Recommended range for most users.

Program version

The ESP module program version is displayed in the display for a second when the wheelchair is started using the main power switch on the control panel.

Example: The ESP module display displays 60 on startup. This means that the ESP module has program version 6.0.

Troubleshooting

When the wheelchair electronics system indicates an error in the output stage, it may also be the ESP module that found an error. The ESP module troubleshoots all vital parts continuously. If an error is found, the wheelchair stops and an error code is displayed in the ESP module display. When the error code has been read off, suitable action can be taken according to the table below.

Error code	Designation	Remark	Check and/or replace
E1	OMNI+/Joystick +	Control panel sending error message	Control panel
E2	Data time out	Interruption in data communication	ESP module, cables, control panel or output stage
E3	Sensor	Sensor error	ESP module
E4	Processor ADC	Sensor error	ESP module
E5	Att Joystick	Additional joystick error	Additional joystick
E6	EPROM	EPROM data error	ESP module, reset factory settings, calibrate
E7	Internal/Code	Software code error	ESP module
E8	Watchdog	Processor error	ESP module
E9	Profile change	Operating error	Switch off the main power switch on the control panel. Switch it on again.

Resetting the basic settings and calibrating the sensor

Calibrate the sensor and return to the settings the ESP module had on delivery from Permobil:

- if the wheelchair does not keep a sufficiently straight course when driven forwards.
- after problems with EPROM data. Error code E6, see page 10.

Resetting and calibrating

- 1. The main power switch on the control panel must be off.
- **2.** Hold down the "S", plus and minus buttons while starting the wheelchair with the main power switch on the control panel.

The display displays "CS". The parameters are reset to the values they had on delivery from Permobil and sensor calibration begins.

Sensor calibration can take up to ten minutes.

When calibration is complete, "-" is displayed in the display.

If calibration fails, "Er" (error) is displayed in the display.

Calibration can be repeated from point one if the error message "Er" was displayed.

3. Exit the programming mode by switching off the wheelchair with the main power switch on the control panel.

Important!

- The ESP module must be completely still during the calibration process.
- Calibration must take place at room temperature, 18 to 25°C.
- The ESP module should be on for at least 20 minutes before calibration begins. This is to ensure that the sensor has the correct working temperature.

ESP User Manual	Notes

ESP User Manual	Notes



Product code: 205008-US-0